



INSTALLATION INSTRUCTIONS

Steps

1. Assemble separately 2 sets of carport feet horizontally on the floor
2. Install 1 set of carport foot with the floor at a right position
3. Install 2nd set of carport foot with the floor remaining inside 5meter distance
4. Install 4 pcs of no 2 C-profiles according to the given distance
5. Install 6 pcs of no 3 C-profiles according to the given distance